



Step 1
 Insert your Key(s) and I.D. Tag at the end of the Cobra Key Holder (Fig. 1), making sure the I.D. Tag is correctly displayed in front of your key(s).

Figure 1

Step 2
 Secure your Key(s) and I.D. Tag to the Cobra Key Holder by looping the bottom end up to the front face of the Cobra Key Holder and insert the tip into the allotted slot (Fig. 2).

Figure 2

Step 3
 The Cobra Key Holder is locked into place (Fig. 3) and ready for the Cobra Key System Wall Board, Pedestal Cart, Roll Cart, Cabinet, or License Plate Holders.

Figure 3

Step 4
 Place the Cobra Key Holder underneath one of the Cobra Key Units and push firmly upward until a solid "click" is heard and felt (Fig. 4).

Figure 4

Step 5
 To release the Cobra Key Holder from the Cobra Key Unit, take the Cobra Master Key or Cobra User Key and insert it into the front of the Cobra Key Unit. Press firmly until the Cobra Key Holder is released from the Cobra Key Unit (Fig. 5).

Figure 5

Step 6
 To release the Cobra User Key from the Cobra Key Unit, re-insert the Cobra Key Holder back into the Cobra Key Unit, until a solid "click" is heard and felt (Fig. 6).

Figure 6